

## FLOW LACQUERED CARE INSTRUCTIONS

### USE

- When preparing food on lacquered wooden products do not place under a heat lamp or on a hot plate
- When storing products avoid areas with high humidity and temperatures

### CLEANING

- Clean using non-scouring sponge with detergent and running water
- Rinse under warm water do not put in dishwasher or leave in standing water
- Wipe down with a cloth and allow to air dry
- This product must NOT be put in a dishwasher, under heat lamps or on hot plates

### MAINTENANCE

- Clean products as above
- Allow to dry fully